

Q. Tell me how you would know if there was a problem with your anti lock braking system

A. The warning light showing 'ABS' will fail to go off after starting the engine or will come on whilst driving if there is a fault with the anti lock braking system.

